




**Check the textile sling before each use.  
They should be discarded if:**



**It is tangled or tied, this can weaken the strength of the sling.**

**The tag is missing or illegible.**

**The cover is nicked, this may indicate that the fibers are damaged.**


**Chemical damage is noticeable on the sling.**

**There are holes in the casing - they may have been caused by welding.**

**The casing has damage caused by friction.**

**The core is visible - the fibers in the core may be damaged.**

**It was used with the wrong type of fasteners.**



**To lift safely every time !**