

Instruction manual

QLR Quick Lift Ring

CODIPROLUX SA
25, Salzbaach L-9559 Wiltz
Tel : +352 26 81 54 1 • Fax : +352 81 05 17
www.codipro.net • info@codipro.net



SAFETY INSTRUCTIONS

About the accessory

Before using the accessory, it is essential for the safety and efficiency of use to read this instruction manual and to comply with all its requirements. This instruction manual must be kept at the disposal of all users.

Read and keep legible the markings on the accessory. Make sure that the user to whom you entrust the accessory is trained and able to assume the safety requirements involved in its use.

Respect a safety perimeter of at least 1 meter for any other person in the work environment. Protect the unit from uncontrolled intervention when it is not in use. The manufacturer declines all responsibility for the consequences of disassembly of the accessory and modifications made beyond its control.

When the device is in an obsolete condition that could cause risks, the user is obliged to neutralize the accessory, i.e. to put it out of operation and possibly disassemble it.

About the handling

The equipment is not designed for lifting people. It is not permitted to pass under a suspended load and/or to expose personnel in the handling area.

Do not exceed the rated load or lift loads not mentioned in the instruction manual. Do not use a damaged or malfunctioning unit or one with missing parts.

Do not leave suspended loads unattended. Do not remove or cover warning labels. Do not operate the equipment without reading and understanding the instruction manual.

Stay away from suspended loads. Do not lift loads higher than necessary. Do not make any repairs, alterations or modifications to the accessory.

Use authorized parts with the accessory only. Follow the entire maintenance program described in this manual.


The operator must be adequately qualified to operate the accessory. Check the accessory before each use, as described in this manual.

During handling, avoid all dangerous operations: shocks, jolts, vibrations, ...

All lifting accessories in contact with the rings must be dimensioned in relation to the rings and comply with the applicable standards. The thread (diameter and/or length) must be appropriate for the material into which it will be screwed. The threaded hole must be clean, conform to the applicable standards and of sufficient length to fit the entire bolt.

DESCRIPTION OF THE ACCESSORY

Overview



RECEPTION OF THE MATERIAL

The material is delivered with an instruction manual and a CE declaration of conformity. Make sure that the equipment is complete and that no components are missing. To do so, refer to the description of the accessory above.

ASSEMBLY AND COMMISSIONING

The material is delivered assembled. It is the user's responsibility to check the suitability of the product for the workstation.

Commissioning is the responsibility of the user company. It is therefore the user's responsibility to carry out the steps and controls according to the standards and regulations in force at the place of use.

CONDITIONS OF USE

The lifting ring is designed to be mounted in a compatible threaded hole, conform to the standards in force, on a part allowing the base to be completely supported on it and allowing the moving parts to articulate without obstacles to movement.



Risk of unscrewing: It is imperative to tighten the lifting ring to the torque indicated on the equipment, using a torque wrench for any application involving rotation of the shackle. In the case of manual tightening, it is the user's responsibility to ensure that the shackle is correctly tightened and that the base plate is fully supported on the load. During the lifting process and in all cases, it is necessary to visually check the correct support of the base plate.

Please be aware of the most common risks associated with the application of inappropriate tightening torques:

- In case of overload
 - weakening of the bolt, which can lead to breakage
- In case of underload
 - unscrewing of the lifting ring while pivoting
 - break of the lifting ring if the base is not perfectly in contact with the load

We strongly recommend checking the tightening torque for any application.



Danger of loosening: The threaded hole and the threaded inserts must be clean and free of defects to allow proper assembly and tightening. Do not press the push button when the lifting ring is under load. This can cause the part to fall off and cause serious damage.

The equipment may only be used by competent and trained personnel in accordance with the standards applicable at the place of use.

The equipment is designed for an operating temperature between -20°C and +200°C. Avoid use in corrosive, aggressive and/or sandy, chemical, acidic, steamy environments, ...

OPERATING PROCEDURE

To mount the ring, press the push button as far as it will go to retract the inserts. Place the bolt in the threaded hole until the ring base makes contact with the bearing surface. Then release the push button, check for complete release and tighten to secure the assembly. Use a hexagonal socket wrench in order not to damage the clamping parts.



Before each lifting operation, make sure that the shackle is correctly oriented in the traction and that the base is properly supported on the load. It is imperative to ensure that the ring is properly screwed and tightened, otherwise unscrewing it may weaken the bolt and lead to material failure. Vibrations can also cause the material to unscrew.

For handling, proceed with the following steps.

- Carry out the routine checks.
- Prepare the work area for the lifting operation.
- Take into account the center of gravity (uneven weight distribution, risk of switchover, ...).
- Make sure that the ring is correctly mounted and locked:
 - Mobility of moving parts
 - Tight contact of the base on the bearing surface
 - Push button completely released
- Hook the shackle of the ring onto a compatible lifting device.
- Apply tension carefully, then start lifting slowly.
- Make sure the mounting is balanced.
- During lifting, steering and transfer, take care to avoid collision with possible obstacles.
- Gently place the load in the prepared area.
- Remove the lifting equipment from the load.



Risk of breakage, risk of loosening: It is forbidden to subject the lifting ring to shocks. The threaded inserts can deteriorate or even break, in particular during a fall from a height of 1 m or more. Any lifting ring that has been subjected to one or more shocks must be removed from service.

Avoid shocks, vibrations, and dangerous maneuvers. Plan and secure the movement to be carried out with the load. Do not stay in a confined space between the load and an obstacle. Avoid unnecessary contact with joints during handling.

WORKING LOAD LIMIT

The Working Load Limit is given in the CE declaration of conformity.



Under no circumstances may the load applied to the lifting ring exceed the WLL of the material.

The use of swivel lifting rings with an angle results in reducing the WLL coefficients. Refer to the Codipro lifting angle tables for the calculation of these coefficients. These are theoretical and strictly indicative. It is the user's responsibility to take into account all safety parameters before lifting. It is also the user's responsibility to ensure the dimensioning of the load. In case of doubt, a case study can be carried out by the manufacturer.

USER TRAINING

Make sure that the users of the accessory have read and understood the contents of this instruction manual.


TRANSPORTATION AND STORAGE

After use, store the ring in a clean, dry place. Take care to avoid shocks during storage and warehousing.

ROUTINE CHECKS

For the routine check, perform the following steps:

- Ensure the integrity of the lifting accessory and its components:
 - o bolt
 - o shackle
 - o flange
 - o base
 - o push button
 - o threaded inserts
 - o screw head
 - o inner shaft
- Make sure that the safety devices function correctly.
 - o Push button engagement: the stop actuation must allow the shaft, located inside the bolt, to come flush with the lower-end surface of the bolt and the inserts to retract completely.
 - o Release of the push button: the button must be able to spring out automatically and allow the threaded inserts to fully extend and engage.



- Ensure that the conform markings are present.
- Ensure that the accessory has not been subjected to shocks.
- Ensure that the accessory has not been subjected to plastic deformation.
- Ensure there are no cracks.
- Ensure that the joints are working properly.
- Ensure there is no excessive or abnormal wear.

SERVICING AND MAINTENANCE

The inspection must be carried out by competent persons at least once a year for normal use, several times a year for intensive use. Routine checks should be performed first. In addition, the following checks must be carried out :

- Condition and wear of the threaded inserts
- Compatibility of the thread - thread hole with thread ring gauges
- Condition of the push button spring
- Condition of the bolt, screw head and the other components
- Articulation of the moving parts
- Correct operation of the anchoring mechanism
- Correct assembly of the components
- Abnormal wear and/or corrosion
- Deformation
- CE marking, traceability engravings, WLL

The accessory must be kept clean. Use a damp cloth for cleaning. Ensure that no particles can interfere with the function of the joints. Ensure that the markings remain legible. Regularly check the parts for wear and tear. All parts of the accessory are subject to stress and wear and may need to be replaced after prolonged use. If a problem is detected during an inspection, do not use the equipment again until the problem has been solved. An unsolved problem can cause serious or lethal accidents.

DECOMMISSIONING

If it is determined that the equipment can no longer be used under normal conditions, ensure that the equipment is no longer being used, for example by sealing it or completely destroying the accessory.

RECYCLING

Most of the materials used are recyclable. Consult local regulations in terms of recycling and reuse.



EC DECLARATION OF CONFORMITY

Fabricant / Manufacturer / Hersteller / Fabricante

Personne autorisée à constituer le dossier technique / Person authorized to compile the technical file / Bevollmächtigter für die Zusammenstellung der technischen Unterlagen / Persona facultada para elaborar el expediente técnico³

CODIPROLUX SA
25, Salzbaach
L-9559 WILTZ



Description de la machine / Description of the machine Beschreibung der Maschine / Descripción del equipo

Accessoire de levage CODIPRO
Lifting Equipment CODIPRO
Anschlagmittelzubehör CODIPRO
Accesorio de elevación CODIPRO

Type d'anneau et dimension / Ring type and dimension / Ringschraubentyp / Tipo de cáncamo y dimensión

QL.DSR

Contrôle anti-fissures / Anti-cracking test / Rissprüfung / Control anti-crack

100 %

Force d'épreuve / Proof force / Prüfkraft / Test de prueba de carga

CMU / WLL x 2,5

Type d'acier / Steelgrade / Stahlsorte / Tipo de acero

Allié/Alloy/Legierung/Legato/Aleación

Conforme à / In compliance with / Entspricht / Conforme a

2006/42/CE - 2006/42/EC - 2006/42/EG
ASME B30.26
EN 10204 - 3.1. Certificate

Testé selon / Tested according to / Geprüft nach / Comprobado segun

EN 1677-1

Les produits hors catalogues sont certifiés pour une utilisation jusqu'à 10 000 cycles / Uncatalogued products are certified for a use up to 10 000 cycles / Wirbelringschrauben, die nicht im Katalog aufgeführt werden, sind bis zu 10 000 Zyklen zertifiziert / Productos descatalogados están certificados para un uso hasta 10 000 ciclos.

« Les anneaux doivent être utilisés conformément à toutes les recommandations décrites dans la notice d'instruction et notre documentation technique » / "The swivel rings must be used in accordance with our recommendations explained in the use recommendations and in technical literature" / „Die Ringschrauben müssen nach den Empfehlungen verwendet werden, die in der Betriebsanleitung und den technischen Dokumenten aufgeführt sind“ / «Los cáncamos deben ser utilizados conforme a todas las recomendaciones descritas en nuestro catálogo técnico y en el manual de instrucciones»

La machine satisfait à l'ensemble des dispositions pertinentes de la directive 2006/42/CE. /The machinery fulfills all the relevant provisions of the Directive 2006/42/EC. / Die Maschine erfüllt alle einschlägigen Bestimmungen der Richtlinie 2006/42/EG. / La máquina cumple todas las disposiciones pertinentes de la Directiva 2006/42/CE.



Christophe LOSANGE, Manager
Responsable autorisé/ Verantwortliche
Person/Authorized person in charge/
Responsable autorizado



www.codipro.net - info@codipro.net

25, Salzbaach – L-9559 WILTZ – Tél : +352 26 81 54 1 - Fax : +352 81 05 17

QL.DSR

QUICK LIFT DOUBLE SWIVEL RING



METRIC THREADS

GradUp



QLR

Quick Lift Ring



1 in = 25.4 mm

Reference	Diameter	SF 5:1 WLL (t)	Standard L ₁ (mm)	Torque (Nm)	S ₂ (mm)	A (mm)	B (mm)	C (mm)	D (mm)	E (mm)	F (mm)	G (mm)	H (mm)	Weight (kg)
QL.DSR M 8	M 8 (x1,25)	0,25	17,5	20	18	31	30	30	38	27	14	53	9,5	0,3
QL.DSR M 10	M 10 (x1,5)	0,40	19,5	30	18	31	30	30	38	27	14	53	9,5	0,3
QL.DSR M 12	M 12 (x1,75)	0,65	23	60	27	40	40	45	53	38	17	76	13	0,9
QL.DSR M 14	M 14 (x2)	0,70	23	80	27	40	40	45	53	38	17	76	13	0,9
QL.DSR M 16	M 16 (x2)	1,05	27	100	27	40	40	45	53	38	17	76	13	0,9
QL.DSR M 20	M 20 (x2,5)	1,70	30	160	40	55	55	60	83	55	25	115	19	2,6
QL.DSR M 24	M 24 (x3)	2,50	36	180	40	55	55	60	83	55	25	115	19	2,6



QL.DSR

QUICK LIFT DOUBLE SWIVEL RING

GradUp



QLR
Quick Lift Ring



1 in = 25.4 mm

Reference	Diameter	SF 5:1 WLL (lbs)	Standard L ₁ (mm)	Torque (ft-lb)	S ₂ (mm)	A (mm)	B (mm)	C (mm)	D (mm)	E (mm)	F (mm)	G (mm)	H (mm)	Weight (kg)
QL.DSR U 050	UNC 1/2"-13	1,300*	23	*	27	40	40	45	53	38	17	76	13	0,9
QL.DSR U 075	UNC 3/4"-10	3,400*	30	*	40	55	55	60	83	55	25	115	19	2,6
QL.DSR U 100	UNC 1"-8	5,000*	36	*	40	55	55	60	83	55	25	115	19	2,6

* In certification process / En cours d'homologation / In Entwicklungsphase / En proceso de homologación